



# CATALOG OF REPLACEMENT PARTS

## MODEL 825A-PLUS & 827E-PLUS SLICERS



825A-Plus




827E-Plus



**Table of Contents**


5	ELECTRICAL AND HOUSING
7	MEAT TABLE AND CARRIAGE
9	KNIFE AND GAUGE PLATE ASSEMBLY
11	SHARPENER ASSEMBLY



**ELECTRICAL AND HOUSING**

**ELECTRICAL AND HOUSING**

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-60096			
1	01-40823E-10001	Deflector - Slicer (825A-PLUS).....	1
2	01-40827E-10000	Deflector - Slicer (827E-PLUS).....	1
3	01-40823E-10002	Pin.....	2
4	01-402101-07041	Nut.....	1
5	01-400839-00093	Set Screw.....	2
6	01-40823E-10025	Knob - Index.....	1
7	01-400839-00093	Set Screw.....	1
8	01-402101-07041	Nut.....	1
9	01-402101-07041	Nut.....	2
10	01-400827-00042	Capacitor.....	1
11	01-40825A-10013	Washer.....	1
12	01-400825-00407	Spacer.....	1
13	01-400825-00405	Cover - Switch Box.....	1
14	01-400825-00006	Washer.....	1
15	01-400825-00021	Screw.....	1
16		Switch (Part no longer available, order Item 35).....	1
17		Cover - Switch (Part no longer available, order Item 35).....	1
18	01-40827E-00093	Foot - Rubber (6mm Threads).....	4
19	01-400823-00061	Set Screw.....	2
20	01-400823-00061	Set Screw.....	1
21	01-400825-0075A	Tie Rod - Center Plate.....	1
22	01-400825-0066B	Belt (Ribbed Flat Belt).....	1
23	FE-021-21	Strain Relief.....	1
24	01-404175-00031	Cord - Power.....	1
25	01-400825-00053	Tie Rod - Motor.....	1
26	01-400825-00055	Plate.....	1
27	01-400825-00006	Washer.....	2
28	01-400825-00056	Nut - Wing.....	1
29	01-402101-07041	Nut.....	2
30	01-400825-0048N	Motor.....	1
31	01-400825-00060	Pin 70MM.....	2
32	01-40827E-10004	Pin - Motor 90MM.....	1
33	01-400827-00058	Screw.....	1
34	01-400825-00006	Washer.....	1
35	01-40823E-10102	Switch (On/Off) (Incls. Item 36).....	1
36	00-915504	Cover - Switch.....	1
37	01-40825A-10014	Screw.....	2




PL-60092

**MEAT TABLE AND CARRIAGE**

**MEAT TABLE AND CARRIAGE**

ILLUS. PL-60092	PART NO.	NAME OF PART	AMT.
1	01-400825-00079	Bushing (2-5/8 In.).....	1
2	01-40825A-10018	Pusher Assy.....	1
3	01-400825-0080A	Handle - Pusher (Red) (6mm Threads).....	1
4	01-40823E-10004	Gasket - Pusher Handle.....	1
5	01-400827-00082	Pad - Wearing.....	1
6	01-40825E-10002	Rod.....	1
7	01-40823E-10005	Bushing.....	1
8	01-400825-00086	Screw - Grub.....	1
9	01-40825E-10001	Table - Product (825A-PLUS).....	1
10	01-40827E-10002	Table - Product (827E-PLUS).....	1
11	01-40823E-10007	Knob (Red).....	1
12	01-40823E-10009	Gasket - Extension.....	1
13	01-40825A-10006	Screw.....	1
14	01-403875-00290	Bracket - Extension (Red).....	1
15	01-40330M-00090	Washer.....	2
16	01-40823E-10019	Screw.....	2
17	01-40825A-10002	Gasket - Tray Support.....	1
18	01-40823E-10018	Knob - Carriage (Red).....	1
19	01-40823E-10016	Gasket - Carriage Handle.....	1
20	01-40823E-10017	Handle - Carriage (Red).....	1
21	01-40825A-10003	Support.....	1
22	01-40829E-10008	Nut.....	2
23	01-40823E-10015	Washer (Aluminum).....	2
24	01-40823E-10014	Washer - Gasket.....	2
25	01-40825A-10004	Screw.....	2
26	01-402101-08515	Washer.....	2
27	01-400825-00089	Screw.....	2
28	01-40825A-10015	Plate - Lexan.....	1
29	01-40825A-00014	Rail - Square.....	1
30	01-400827-00021	Screw.....	2
31	01-40825A-10005	Spacer.....	1
32	01-40300M-00098	Nut.....	1
33	01-400825-00020	Spring.....	1
34	01-400825-00050	Screw.....	2
35	01-400823-00218	Bushing.....	1
36	01-40825A-10007	Carriage.....	1
37	01-400825-00015	Bearing.....	2
38	01-400825-00089	Screw.....	2
39	01-400823-00218	Bushing.....	1
40	01-400825-00020	Spring.....	1
41	01-400825-00013	Rail - Round.....	1
	01-40825A-10008	Carriage Assy.....	1




PL-60097

### KNIFE AND GAUGE PLATE ASSEMBLY



**KNIFE AND GAUGE PLATE ASSEMBLY**

ILLUS. PL-60097	PART NO.	NAME OF PART	AMT.
1	01-40829E-00404	Seal - Rubber.....	1
2	01-400823-00123	Washer.....	1
3	01-400825-00101	Screw.....	1
4	01-400827-0103A	Knob (Red).....	1
5	01-400825-00073	Knife (825A-PLUS).....	1
6	01-40827E-00073	Knife (827E-PLUS).....	1
7	01-400825-00074	Screw - Knife.....	4
8	01-400825-00135	Insert - Cover.....	1
9	01-400823-00403	Knob - Knife Cover (Aluminum).....	1
10	01-400825-00401	Plate - Center (825A-PLUS).....	1
11	01-400827-00401	Cover - Blade (827E-PLUS).....	1
12	01-400827-00074	Screw - Knife.....	1
13	01-40825A-10009	Plate - Gauge (825A-PLUS).....	1
14	01-40827E-10003	Plate - Gauge (827E-PLUS).....	1
15	01-400825-00408	Guard - Ring (825A-PLUS).....	1
16	01-40827E-00408	Guard - Ring (827E-PLUS).....	1
17	01-40823E-10022	Washer.....	2
18	01-400825-00021	Screw.....	2
19	01-40829E-00402	Screw.....	3
20	01-40829E-00403	Ring.....	1
21	01-400825-067-1	Knife Pulley Assy. (Flat Belt) (825A-PLUS).....	1
22	01-40827E-00067	Knife Pulley Assy. (Flat Belt) (827E-PLUS).....	1
23	01-40825A-00026	Plate.....	1
24	01-400825-00021	Screw.....	2
25	01-400825-00140	Bushing.....	1
26	01-400825-00030	Pin.....	1
27	01-402101-07041	Nut.....	1
28	01-400827-00028	Screw (Brass).....	1
29	01-400823-00405	Washer.....	1
30	01-40825A-10010	Support - Gauge Plate.....	1
31	01-403301-03812	Washer.....	2
32	01-400825-00089	Screw.....	2
33	01-40825A-00024	Spring.....	1
34	01-400827-00031	Set Screw.....	1
35	01-40825A-00022	Support (Incls. Grub Screw, Brass Screw, & Nylon Pin).....	1
36	01-40825A-00025	Cam.....	1
37	01-400827-00095	Washer - Spring.....	1
38	01-400825-00027	Pin - Cam.....	1
39	01-402101-07041	Nut.....	1
40	01-40825A-10012	Bushing.....	1



PL-60098

**SHARPENER ASSEMBLY**

**SHARPENER ASSEMBLY**

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-60098			
1	01-400823-00123	Washer.....	1
2	01-400825-00122	Screw.....	1
3	01-412062-00RED	Flag - Berkel.....	1
4	01-4V6371	Screw.....	1
5	01-40825A-00010	Cover - Sharpener (Aluminum).....	1
6	01-400823-00400	Cover - Sharpener.....	1
7	01-402101-02109	Screw.....	1
8	01-400825-00108	Frame - Sharpener.....	1
9	01-403301-03812	Washer.....	1
10	01-40825A-10016	Button - Push.....	1
11	01-400825-00117	Spring.....	1
12	01-400825-00117	Spring.....	1
13	01-403301-03812	Washer.....	1
14	01-402101-07041	Nut.....	1
15	01-403375-01419	Shaft - Sharpener (825A-PLUS).....	1
16	01-403375-01420	Shaft - Sharpener (827E-PLUS).....	1
17	01-400825-00109	Shaft.....	1
18	01-400825-00112	Stone.....	1
19	01-403301-03812	Washer.....	1
20	01-402175-00387	Nut.....	1
21	01-40825A-10017	Button - Push.....	1
22	01-400825-00112	Stone.....	1
23	01-400825-00110	Shaft.....	1
24	01-402175-00387	Nut.....	1
25	01-403301-03812	Washer.....	1
	01-400825-00130	Sharpener Assy. (825A-PLUS).....	1
	01-40827A-00130	Sharpener Assy. (827E-PLUS).....	1

