



MODEL 116C

PARTS LIST

8/18/2015

Model: 116C, 116CL 30LB DESIGNER SERIES ELECTRIC FRYER				
Key No	Part No	Qty	Description	Application
1	2T-Y1668	1	SAFETY THERMOSTAT	
2	2T-Z7208	1	THERMOSTAT	
3	2R-9790	1	THERMOSTAT KNOB	
4	E1-116313	1	SIGNAL LIGHT-HEATING	AMBER
5	E1-116314	1	SIGNAL LIGHT-POWER	WHITE
6	E1-116323	1	ELEMENT HOUSING COVER	
7	2I-9918	1	GASKET	
8	E1-7434	1	RELEASE LOCKING MECHANISM	
9	E1-116015	1	CRANK ASSEMBLY	
14	E1-116015	1	CRANK ASSEMBLY	
10	E1-7431	2	ROD-LOCKING	
11	E1-7431	2	ROD-LOCKING	
12	E1-116016	1	ECCENTRIC ASSEMBLY	
15	E1-116311	1	ELEMENT HOUSING ASSY COMPLETE	208V
	E1-116332		ELEMENT HOUSING ASSY COMPLETE	240V
	E1-11303	1	ELEMENT HOUSING	
16	E1-7310	1	SUPPORT LEFT	
17	2E-Y6240	2	CONTACTOR	208/240V
18	2E-Y2849	1	TERMINAL BLOCK, POWER	
19	2E-Y1654	1	TERMINAL BLOCK, FIRE	
20	E1-Y1684	1	COVER - BACK	
25	Z1-115006, NLA	4	FOOT ASSEMBLY, (LESS FOOT)	
	2A-9347	4	FOOT EXTENSION	
	2C-9348	4	STUD	
	2C-7612	4	FOOT	
26	2P-7413	2	TIMER - BELL	
29	2E-8343	1	ON/OFF SWITCH, TOGGLE	(#1169486 & BELOW)
	2E-Y6144		ON/OFF SWITCH, ROCKER	(#1169787 & UP)
30	2R-7412	2	DIAL - BELL TIMER	
31	2R-4717	2	KNOB - BELL TIMER	
33	J1-6305	2	SIDE PANEL	
37	E1-116318	1	KETTLE ASSEMBLY	
39	E1-7311	1	SUPPORT RIGHT	
40	2N-Y5554	3	ELEMENT	240V
	2N-Y5555			208V
NI	E1-116320	1	ELEMENT HANDLE ASSY	
	E1-Y1641	1	ELEMENT CLAMP - UPPER	
	2I-5659	2	GROMMET - CAPILLARY	
	E1-7363	5	CLAMP - CAPILLARY BULB	
	2P-Y3406	4	SPACER - CAPILLARY BULB	
	E1-116318	1	TOP ASSEMBLY	116C
	E1-116154	1	TOP ASSEMBLY	116CL
	E1-115754	2	FUSE HOLDER ASSY	208/240V
	2E-Y3242	2	FUSE	208/240V
	2B-Y8847	1	BASKET-LEFT (8" WIDE)	116C
	2B-Y8846	1	BASKET-RIGHT (8" WIDE)	116C
	2B-116111	1	BASKET - LEFT (8" WIDE)	116CL
2B-116112	1	BASKET - RIGHT (8" WIDE)	116CL	