



**Star
Manufacturing
International Inc.**

10 Sunnen Dr.
St. Louis, MO 63143

Phone: (14) 678-6303
FAX: (314) 781-2714

**Installation
and
Operating
Instructions**

2M-Y5707 Rev. C 8/15/95

SOUP KETTLE COOKERS and HOLDERS MODELS 7C, 7H, 11C, 11H





CAUTION

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations.

INSTALLATION

These food warmers are equipped for the voltage and wattage indicated on the nameplate mounted to the back panel and are designed for use on alternating current (AC) only. Serious damage may result if appliance is used with incorrect voltage.



CAUTION

DO NOT CONNECT TO DIRECT CURRENT (DC).

GENERAL OPERATING INSTRUCTIONS

1. Before using the soup kettle, clean the water and soup bowls and its cover if furnished with the kettle.
2. Do not operate the kettle dry. Place water in the water bowl (14 ounces of water for 11 qt. Model, 26 ounces for the 7 qt. Model).
3. The temperature control on these kettles is a combination On/Off switch with an infinite control. The "OFF" position will turn off the electric current to the heating element.
4. If PRE-HEATING IS DESIRED SET THE CONTROL AT "HI" for approximately 20-30 minutes. Prolonged "HI" setting may result in overcooking or scorching of certain food.
5. Set the dial to the number required to maintain the temperature desired. Because the consistency of different food varies, and because liquids and solids absorb heat at different rates, it is impractical to specify the exact dial setting. Therefore, we have indicated the setting with a series of numbers. A little experience will give you the proper setting for various foods you are serving.
6. The soup cookers are equipped with a warning light to prevent overheating or scorching of certain soups. When the light is on, all electric current to the heating elements will be off. Turn the heat setting down to a lower setting and wait 5-10 minutes for the light to go out. It would also be advisable to check the water level in the water bowl.
7. Turn the control to the "OFF" position when the unit is not in use.



CAUTION

DO NOT OVER-HEAT THE UNIT.

CLEANING INSTRUCTIONS

Change water in water bowl daily and remove any food collection that may have entered the water bath. Clean soup bowl, cover and the kettle at a sink with soap and water.

The exterior surfaces of the warmer can be kept clean and attractive by wiping or washing regularly with a soft cloth and mild soap and water. Any discoloration on the bowls and cover can be removed with a non-abrasive cleaner. **Do not use an abrasive cleaner as the attractive coatings will be affected adversely.**


MAINTENANCE AND REPAIRS

Contact the factory, a service representative or a local service company for service or required maintenance.

<p>MATERIAL ~</p>	<p>FINISH ~</p>	<p>MODEL NO. 7C/H,11C/H</p> <p>PART NO. SK1240</p>
<p>TITLE WIRING DIAGRAM</p>		
<p>DR. B.N. CK. DATE 3/17/92</p> <p>LIMITS UNLESS OTHERWISE NOTED</p> <p>FRACTIONS 1/64 DECIMALS .005 ±</p>	<p>CHANGES LTR DATE CHANGE DR</p> <p>B 3/17/92 REDRAWN TO CAD</p>	<p>B.N.</p>
<p>STAR MFG. INTERNATIONAL, INC. 9325 OLIVE BOULEVARD ST. LOUIS, MO 63132</p> <div style="display: flex; justify-content: space-around;"> <div data-bbox="389 504 730 945"> <p>MODELS 7C & 11C COOKERS 120V & 240V</p> </div> <div data-bbox="730 504 1071 945"> <p>MODELS 7H & 11H HOLDERS 120V & 240V</p> </div> </div>		


MATERIAL		FINISH		MODEL NO.		PART NO.	
~		~		7C/11C-E		SK1241	
DR.B.NCK.		DATE 3/18/92		TITLE WIRING DIAGRAM			
LIMITS UNLESS OTHERWISE NOTED		FRACTIONS 1/64 DECIMALS .005 + -		LTR DATE		CHANGE	
						DR	

MODELS 7C & 11C COOKERS
240V EUROPE



2M-Y5707: Star Soup Kettle, 7C-B & 11C-B





2M-Y5707: Star Soup Kettle, 7C-B & 11C-B

PARTS LIST

January 30, 2014

Model: 7C-B, 11C-B Soup Kettle				
Key No	Part No	Qty	Description	Application
1	2D-Y5670	1	SOUP KETTLE COOKER - BLACK	
2	2D-Y5660	1	TRANSFER COLLAR RING - BLACK (does not include gasket)	7C-B
3	2D-Y5664	1	TRANSFER COLLAR RING - BLACK (does not include gasket)	11C-B
4	O2-71109	1	COVER ASSEMBLY (does not include hinge parts)	7C-B
5	O2-71110	1	COVER ASSEMBLY (does not include hinge parts)	11C-B
NI	2I-Y5712	1	GASKET RING	
6	2R-Y5701	1	INSULATING HANDLE	
7	O2-Y5703	1	HINGE LEAF	
8	O2-Y5704	1	HINGE RING BRACKET	
9	2B-Y5792	2	PIN - HINGE	
10	2A-Y5684	2	FOOT - BLACK	
11	O2-Y6209	2	SIGN CLIP	
12	2M-Y5686	1	SOUP SIGN PACKET (21 SIGNS)	
NI	2D-Y5696	1	POT - 7 QT BAIN MARINE	7C-B
NI	2D-Y5698	1	POT - 11QT BAIN MARINE	11C-B
13	2D-Y9029	1	LINER - WATER	
NI	2N-Y5677	1	ELEMENT - 1000W	120V
NI	2N-Y5679	1	ELEMENT - 1000W	240V
NI	O2-Y5680	1	BAND - ELEMENT	
14	2R-9193	1	BUTTON INDICATOR	
NI	2J-6402	1	INFINITE CONTROL	120V
NI	2J-6403	1	INFINITE CONTROL	240V
15	2R-Y5682	1	KNOB CONTROL	
16	2M-Y5695	1	LABEL - "CHECK HEAT/WATER"	
17	O2-71107	1	PILOT LIGHT	120V
	O2-71108			240V
NI	2T-Y5708	1	THERMOSTAT - HI-LIMIT	
NI	O2-Y5709	1	BRACKET - THERMOSTAT	
NI	Z1-S7523	1	CORD SET ASSEMBLY	120V
NI	A1-S7554	1	CORD SET ASSEMBLY	240V
NI	2K-Y2967	1	BUSHING, POWER CORD	
NI	O2-Y5689	1	BOTTOM	

2M-Y5707: Star Soup Kettle, 7C-B & 11C-B

STAR INTERNATIONAL HOLDINGS INC. COMPANY
Star - Holman - Lang - Wells - Bloomfield - Toastmaster
10 Sunnen Drive, St. Louis, MO 63143 U.S.A.
(314) 678-6303
www.star-mfg.com